

# USB Headset Integration for iPECS ONE

## Instructions

1. Can I suggest this is tried on a new PC, which you have not tried to use previously, just to avoid any crossover of previous downloads
  - a. If not, please be sure to delete **both** the Chrome extension & the download file previously.
2. Use a Windows PC
3. Do not plug-in a BL-054MS+P cord
4. Open a new Chrome window
  - a. Add the Chrome Extension as below
  - b. Chrome Extension [link](#)
  - c. Close the Chrome Window
5. Download the attached file
  - a. Extract the .zip file and install the program
  - b. [Link](#)
6. Open a new Chrome Window
  - a. Check the Chrome Extension is active
7. Open iPECS One version 2.1.1 and login
8. Plug-in the BL-054MS+P cord
9. Check the Headset Integration settings are on and select the BL-054MS+P cord
10. There should NOT be a message saying 'Not Integrated'
11. Take a test call

**NOTE:** The above instructions also work for the Athena HS-D2 headset with the USB function. At step three – do not plug the USB cable into the PC.